


# Callisto Assembly Instructions

Fittings Included	Assembly Instructions		Tools Required
Workstation		<ol style="list-style-type: none"><li>1 Remove plate from each leg assembly using Allen Key</li><li>2 With legs upright, push beam into leg assemblies, locating the dowel pins into the holes in beam</li><li>3 Secure legs to beam using plates and allen screws previously removed</li><li>4 Evenly fit plastic cable holders to beam on chosen side</li></ol>	Flat Screwdriver
Screws		<p>Workstations supplied with a corner leg (e.g. Cresents) attach corner leg by inserting threaded bar through corner of beam - secure with 10mm nut</p> <ol style="list-style-type: none"><li>5 With workstation top face down, on a flat surface, fix the frame assembly to top with rail screws</li><li>6 Stand the workstation upright and clip cable covers to legs and clip 'e' covers in end of beam</li></ol>	Pozi Screwdriver  Allen Key (Supplied)