

Kassini Assembly Instructions

Fittings Included



Workstation



Screws x 4

Assembly Instructions



- 1 Interlock the Modesty Panel ends into the legs and tighten
- 2 Replace interlocking infill panel on legs
- 3 Insert 40mm Screws through upper leg casts and into pilot holes in table top

Tools Required



Pozi Screwdriver